


DIP SWITCH No.1 SETTINGS

1. COIN SWITCH No.1 SETTINGS

SW	1	2	3	4	COIN	PLAY
0	OFF	OFF	OFF	OFF	1	1
	ON	OFF			1	2
	OFF	ON			1	3
	ON	ON			1	4
	OFF	OFF	ON	OFF	1	5
	ON	OFF			1	6
	OFF	ON			1	7
	ON	ON			2	1
	OFF	OFF	OFF	ON	2	3
	ON	OFF			2	5
	OFF	ON			3	1
	ON	ON			3	2
	OFF	OFF	ON	ON	3	4
	ON	OFF			4	1
	OFF	ON			4	3
	ON	ON				FREE PLAY

2. COIN SWITCH No.2 SETTINGS

SW	6	7	8	COIN	PLAY
0	OFF	OFF	OFF	1	1
	ON	OFF		1	2
	OFF	ON		1	3
	ON	ON		1	4
	OFF	OFF	ON	1	5
	ON	OFF		1	6
	OFF	ON		1	7
	ON	ON		2	1
	OFF	OFF	OFF	2	3
	ON	OFF		2	5
	OFF	ON		3	1
	ON	ON		3	2
	OFF	OFF	ON	3	4
	ON	OFF		4	1
	OFF	ON		4	3
	ON	ON			VOID



DIP SWITCH No.3 SETTINGS

1. VIDEO SCREEN FLIP

SW	1	MONITOR
0	OFF	NORMAL
	ON	UPSIDE DOWN

2. CHANGE OF MODE

SW	3	MODE
0	OFF	GAME MODE
	ON	TEST MODE

★SW 2: NOT USED

SW 4: NOT USED

0 recommended

Self Test

Normal: "OK" will be displayed, and then the game will start.
Abnormal: "BAD" will be displayed and the screen will stop.

Manual Test

How to start.

Turn on the SW3 of DIP SW3 and power on.

Test item.

①Conditioning of Pictures Contortion.

②Sound Check.

③Color Conditioning.

④Control Check.

⑤Coin Counter Check.

⑥DIP SW SET.

⑦To change items.

Push 1P START button

INSTRUCCIONES DEL JUEGO

2 jugadores pueden jugar a la vez
8 pantallas en total

1. Recorrido de Obstaculos

Golpear el botón RUN repetidamente y presionar el botón JUMP para saltar en la pared o por encima.

2. Disparos en serie (I)

Usar el JOYSTICK para apuntar a los blancos y disparar tanto como sea posible.

3. Carrera del HOMBRE DE HIERRO

Usar el JOYSTICK para conducir el jugador y golpear repetidamente el botón de RUN. Salta por encima de estanques y rocas.

4. Disparos en serie (II)

Usar el JOYSTICK para mover el jugador y disparar tanto como sea posible.

5. Brazo de Lucha

Golpear más rápido el botón RUN para conseguir mas potencia.

6. Disparos serie (III)

No disparar los blancos con la figura del hombre en ellos.

7. Combate con Instructor

Usar el JOYSTICK para mover el jugador y presionar el botón de JUMP o de ACTION.

8. Combate real

Usar el JOYSTICK para mover el jugador y apretar el botón de JUMP o ACTION para vencer a los enemigos.

FOR JOYSTICK

CONTROL FOR 2P

SAME AS 1P CONTROLS


2P RIGHT (ORANGE)
2P LEFT (YELLOW)
2P DOWN (GREEN)
2P UP (BLUE)

DINUNNO INTL, S. A.
C/. CÒRSEGA, n.º 381
TEL. 207 11 16
08037 - BARCELONA

8 2P RIGHT
7 2P LEFT
6 2P DOWN
5 2P UP
4 1P RIGHT
3 1P LEFT
2 1P DOWN
1 1P UP

38T 8PIN POST V/DASE
BBPB-VH
3.95MM PITCH

CONTROL FOR 1P



1P RIGHT (PURPLE)
1P LEFT (GRAY)
1P DOWN (PINK)
1P UP (SKY BLUE)

- NOTES -

- 1 1P NO.
- 2P NO
- 2 SURGE
- COUNT